

#Jenny



Finally I get this ebook, thanks for all these I can get now!

#Rio



Cool! I'am really happy

#Markus Jensen



I did not think that this would work, my best friend showed me this website, and it does! I get my most wanted eBook

#Hun Tsu



wtf this great ebook for free?!

#Che Salsa



My friends are so mad that they do not know how I have all the high quality ebook which they do not!

#Diego Butler



so many fake sites. this is the first one which worked! Many thanks

ENGINE MECHANICAL (L&RE) EN02-37

IMPORTANT POINTS - ASSEMBLY

- 1. INSTALL THE REAR END PLATE.**
(1) Apply lock-washer (DIN Lock Washer SM or equivalent) to the threads of the two bolts in the side of the air compressor fitting (2) plate and tighten to the specified torque using the special tool SST. Socket wrench (50941-11300)
Tightening Torque:
50 Nm (36.9 kg/cm, 41 lbf ft)
- 2. INSTALL THE CRANKSHAFT GEAR.**
(1) Heat the crankshaft gear in oil heated to 100°C -150°C (212°F - 302°F).
WARNING
Never touch the heated gear with your bare hand. This can result in personal injury.
(2) Align the crankshaft gear groove with crankshaft pin.
(3) Install the crankshaft gear onto the crankshaft as shown in the figure.
Dimension A: 27 mm (0.866 in.)
- 3. INSTALL THE OILER GEAR SHAFT AND GEAR.**
- EXCEPT J56-05, J56

www.epcatalogs.com

[Download PDF version of :](#)
Hino Eh700 Workshop Manual Book